


1/2/23 - Oticon Connect Clip.

Plugged into the USB Charger MI MAC PRO.

went to cook Dinner and came back in two hours.

Resumed the video I was watching and the audio resumed and then 2/10 seconds it stopped and became intermittent.



← when music/Audio skips this light changes blue for <1-2 seconds.

Tried

- Factory Reset the Connect Clip.
- HAs powered off and On.
- Repaired with MI Mac Pro.

Next

- Email Audiologist about the issue.